



SOLDER WIRE TO SOLDER CUP CONTACTS.
INSERT CONNECTOR INTO CLAMSHELL HOOD.
SNAP TOGETHER AND ASSEMBLE WITH SCREWS.