



HN connector instruction

Not scale drawing


Sheet 1 of 2

Date:	10/02/2011
Revision:	0.0
Dimensions:	IN (mm)
Number:	

Property and confidential


The information contained in this drawing is the sole property of Vaqtec Srl. Any reproduction in part or as a whole without the written permission of Vaqtec Srl is prohibited.





SLIDE SHELL OVER CABLE ASSEMBLY AND PUSH CABLE ASSEMBLY INTO SHELL AS FAR AS IT WILL GO. MAKE SURE SHARP EDGE OF GLAND SEATS PROPERLY IN GASKET.

FIG 7



SLIDE NUT INTO SHELL AND TIGHTEN IN PLACE WITH WRENCH UNTIL TIGHT. MAKE SURE TO HOLD CABLE AND SHELL RIGID WHILE ROTATING NUT.

vag	tec
vacuum technology	& components

HN connector instruction

Not scale drawing

Sheet 2 of 2

Date:	10/02/2011
Revision:	0.0
Dimensions:	IN (mm)
Number:	

Property and confidential

The information contained in this drawing is the sole property of Vaqtec Srl. Any reproduction in part or as a whole without the written permission of Vaqtec Srl is prohibited.